

Sec. 29-349-223. Blasting cap containers

Electric blasting caps shall be kept in their original container or in a closed metal box lined with a soft material such as wood or sponge rubber. The coils and folds in the wires of electric blasting caps should not be straightened out until made ready for use.

(Effective December 24, 1987)